

LIST OF EFFECTIVE PAGES

Page	Date of issue
0 - 1	Jan 10, 2010
0 - 2	Mar 20, 2000
0 - 3	Jun 8, 2016
0 - 4	Jun 8, 2016
0 - 5	Oct 15, 2002
0 - 6	Jun 8, 2016
0 - 7	Mar 1, 1996
0 - 8	Mar 1, 1996
1 - 1	Mar 1, 1996
1 - 2	Mar 1, 1996
1 - 3	Jan 10, 2010
1 - 4	Mar 1, 1996
1 - 5	Mar 20, 2000
1 - 6	Mar 1, 1996
1 - 7	Mar 1, 1996
1 - 8	Jun 8, 2016
1 - 9	Mar 1, 1996
1 - 10	Mar 1, 1996
1 - 11	Mar 1, 1996
1 - 12	Mar 1, 1996
2 - 1	Mar 1, 1996
2 - 2	Jan 10, 2010
2 - 3	Mar 1, 1996
2 - 4	Mar 1, 1996
2 - 5	Oct 15, 2002
2 - 6	Oct 15, 2002
2 - 7	Mar 1, 1996
2 - 8	Mar 1, 1996
2 - 9	Mar 1, 1996
2 - 10	Oct 15, 2002
2 - 11	Oct 15, 2002
2 - 11A	Oct 15, 2002
2 - 11B	Oct 15, 2002
2 - 12	Mar 1, 1996
2 - 13	Mar 1, 1996
2 - 14	Mar 20, 2000
2 - 15	Jan 10, 2010
2 - 16	Mar 1, 1996
2 - 17	Mar 1, 1996
2 - 18	Oct 15, 2002
2 - 18A	Oct 15, 2002
2 - 18B	Oct 15, 2002
2 - 19	Mar 1, 1996
2 - 20	Mar 1, 1996
2 - 21	Mar 1, 1996

Page	Date of issue
2 - 22	Mar 20, 2000
2 - 23	Mar 20, 2000
2 - 24	Mar 1, 1996
2 - 25	Mar 1, 1996
2 - 26	Mar 1, 1996
2 - 27	Mar 1, 1996
2 - 28	Mar 1, 1996
2 - 29	Oct 15, 2002
2 - 30	Mar 1, 1996
2 - 31	Mar 1, 1996
2 - 32	Oct 15, 2002
2 - 33	Oct 15, 2002
2 - 33A	Oct 15, 2002
2 - 33B	Oct 15, 2002
2 - 34	Aug 15, 2003
2 - 35	Oct 15, 2002
2 - 36	Oct 15, 2002
2 - 37	Jun 8, 2016
2 - 38	Mar 20, 2000
2 - 39	Mar 1, 1996
2 - 40	Mar 1, 1996
2 - 41	Oct 15, 2002
2 - 42	Mar 1, 1996
2 - 43	Mar 1, 1996
2 - 44	Mar 1, 1996
2 - 45	Mar 1, 1996
2 - 46	Mar 1, 1996
2 - 47	Mar 1, 1996
2 - 48	Mar 1, 1996
2 - 49	Mar 1, 1996
2 - 50	Mar 1, 1996
2 - 51	Oct 15, 2002
2 - 52	Oct 15, 2002
2 - 53	Oct 15, 2002
2 - 53A	Oct 15, 2002
2 - 53B	Oct 15, 2002
2 - 53C	Oct 15, 2002
2 - 53D	Oct 15, 2002
2 - 54	Oct 15, 2002
2 - 55	Oct 15, 2002
2 - 56	Oct 15, 2002
2 - 57	Oct 15, 2002
2 - 57A	Oct 15, 2002
2 - 57B	Oct 15, 2002
2 - 57C	Oct 15, 2002
2 - 57D	Oct 15, 2002
2 - 58	Oct 15, 2002

Page	Date of issue
2 - 58A	Oct 15, 2002
2 - 58B	Oct 15, 2002
2 - 59	Oct 15, 2002
2 - 59A	Oct 15, 2002
2 - 59B	Oct 15, 2002
2 - 60	Oct 15, 2002
2 - 61	Oct 15, 2002
2 - 61A	Jan 10, 2010
2 - 61B	Oct 15, 2002
2 - 62	Oct 15, 2002
2 - 63	Oct 15, 2002
2 - 63A	Oct 15, 2002
2 - 63B	Oct 15, 2002
2 - 63C	Jan 10, 2010
2 - 63D	Jan 10, 2010
2 - 64	Oct 15, 2002
2 - 65	Oct 15, 2002
2 - 65A	Oct 15, 2002
2 - 65B	Oct 15, 2002
2 - 66	Mar 1, 1996
2 - 67	Mar 20, 2000
2 - 68	Oct 15, 2002
2 - 69	Oct 15, 2002
2 - 70	Oct 15, 2002
2 - 71	Oct 15, 2002
2 - 72	Oct 15, 2002
2 - 73	Oct 15, 2002
2 - 74	Oct 15, 2002
3 - 1	Mar 1, 1996
3 - 2	Mar 1, 1996
3 - 3	Jun 20, 2006
3 - 4	Mar 1, 1996
3 - 5	Mar 8, 2007
3 - 6	Mar 8, 2007
3 - 7	Oct 15, 2002
3 - 8	Mar 20, 2000
3 - 9	Mar 20, 2000
3 - 10	Mar 1, 1996
3 - 11	Mar 1, 1996
3 - 12	Mar 20, 2000
3 - 13	Mar 1, 1996
3 - 14	Apr 30, 1999
3 - 15	Mar 1, 1996
3 - 16	Mar 1, 1996

LIST OF EFFECTIVE PAGES

Page	Date of issue	Page	Date of issue	Page	Date of issue
4 - 1	Mar 1, 1996	5 - 15	Mar 1, 1996	7 - 1	Mar 20, 2000
4 - 2	Mar 1, 1996	5 - 16	Mar 1, 1996	7 - 2	Mar 1, 1996
4 - 3	Mar 1, 1996	5 - 17	Mar 20, 2000	7 - 3	Mar 1, 1996
4 - 4	Mar 1, 1996	5 - 18	Jun 20, 2006	7 - 4	Mar 1, 1996
4 - 5	Jan 14, 2005	5 - 19	Mar 1, 1996	7 - 5	Mar 1, 1996
4 - 6	Jan 14, 2005	5 - 20	Mar 1, 1996	7 - 6	Mar 1, 1996
4 - 7	Mar 1, 1996	5 - 21	Mar 20, 2000	7 - 7	Mar 1, 1996
4 - 8	Mar 1, 1996	5 - 21a	Oct 7, 2002	7 - 8	Mar 20, 2000
4 - 9	Mar 1, 1996	5 - 21b	Nov 1, 2010	7 - 9	Mar 1, 1996
4 - 10	Oct 15, 2002	5 - 22	Mar 1, 1996	7 - 10	Mar 20, 2000
4 - 11	Mar 1, 1996	5 - 23	Mar 1, 1996	7 - 11	Mar 1, 1996
4 - 12	Mar 20, 2000	5 - 24	Mar 1, 1996	7 - 12	Mar 1, 1996
4 - 13	Jun 20, 2006	5 - 25	Mar 1, 1996	7 - 13	Mar 20, 2000
4 - 13a	Mar 20, 2000	5 - 26	Nov 1, 2010	7 - 14	Mar 20, 2000
4 - 13b	Mar 20, 2000			7 - 15	Mar 1, 1996
4 - 14	Oct 15, 2002	6 - 1	Aug 15, 2003	7 - 16	Mar 1, 1996
4 - 15	Mar 1, 1996	6 - 2	Mar 1, 1996	7 - 17	Mar 1, 1996
4 - 16	Mar 1, 1996	6 - 3	Mar 1, 1996	7 - 18	Mar 20, 2000
4 - 17	Mar 20, 2000	6 - 4	Mar 1, 1996	7 - 19	Mar 1, 1996
4 - 18	Mar 20, 2000	6 - 5	Mar 1, 1996	7 - 20	Mar 1, 1996
4 - 19	Mar 1, 1996	6 - 6	Mar 1, 1996	7 - 21	Oct 24, 2014
4 - 20	Mar 1, 1996	6 - 7	Mar 1, 1996	7 - 22	Mar 20, 2000
4 - 21	Mar 1, 1996	6 - 8	Mar 20, 2000	7 - 23	Mar 1, 1996
4 - 22	Mar 1, 1996	6 - 9	Mar 1, 1996	7 - 24	Mar 1, 1996
4 - 23	Mar 1, 1996	6 - 10	Mar 1, 1996	7 - 25	Mar 20, 2000
4 - 24	Jan 10, 2010	6 - 10A	Aug 15, 2003	7 - 26	Mar 20, 2000
4 - 25	Mar 1, 1996	6 - 10B	Aug 15, 2003	7 - 27	Mar 20, 2000
4 - 26	Aug 15, 2003	6 - 10C	Aug 15, 2003	7 - 28	Mar 1, 1996
4 - 27	Mar 1, 1996	6 - 10D	Aug 15, 2003	7 - 29	Mar 20, 2000
4 - 28	Mar 1, 1996	6 - 11	Mar 20, 2000	7 - 30	Mar 20, 2000
		6 - 12	Aug 15, 2003	7 - 31	Mar 20, 2000
5 - 1	Oct 10, 1997	6 - 13	Aug 15, 2003	7 - 32	Mar 1, 1996
5 - 2	Mar 1, 1996	6 - 14	Mar 1, 1996	7 - 33	Mar 20, 2000
5 - 3	Mar 20, 2000	6 - 15	Mar 1, 1996	7 - 34	Mar 20, 2000
5 - 4	Mar 20, 2000	6 - 16	Jan 14, 2005		
5 - 5	Jun 1, 2013	6 - 17	Mar 1, 1996	9 - 1	Mar 15, 2016
5 - 6	Jun 1, 2013	6 - 18	Mar 1, 1996	9 - 2	Mar 15, 2016
5 - 7	Jun 1, 2013	6 - 19	Mar 20, 2000	9 - 3	Mar 15, 2016
5 - 8	Jun 1, 2013	6 - 20	Mar 1, 1996	9 - 4	Mar 15, 2016
5 - 9	Jun 1, 2013	6 - 21	Oct 15, 2002	9 - 5	Mar 15, 2016
5 - 10	Jun 8, 2016	6 - 22	Mar 1, 1996	9 - 6	Mar 15, 2016
5 - 11	Jun 1, 2013	6 - 23	Mar 1, 1996	9 - 7	Mar 15, 2016
5 - 12	Jun 1, 2013	6 - 24	Mar 1, 1996	9 - 8	Mar 15, 2016
5 - 13	Apr 13, 2001				
5 - 14	Mar 1, 1996				

NOTE:

List of effective pages of Section 8 is not a part of this List. It is includes in the above mentioned section 8.

LOG OF REVISION

Rev. No.:	Description / eligibility	Pages affected:	Date of issue of new page	Date of revision incorporating and signature
11	Revision of the airworthiness limitation	0-3, 0-4, 0-6, 9-1, 9-2, 9-3, 9-4	Apr 15, 2003	
12	Revision of the airworthiness limitation	0-3, 0-4, 0-6, 9-1, 9-3	Apr 23, 2003	
13	1. Supplement of list of parts with limited operation time for aircraft operation over 5500 flight hours. 2. Formal arrangements of accompanying technical documentation.	0-3, 0-4, 0-6, 2-34, 4-26, 5-12, 6-1, 6-10A, 6-10B, 6-10C, 6-10D, 6-12, 6-13, 9-1, 9-2, 9-3, 9-4	Aug 15, 2003	
14	Operation on condition of the nose landing gear type 793-HPK-185-19, 793-HPK-185-19-7	0-3, 0-4, 0-6, 1-3, 3-6, 5-10, 5-18	Nov 20, 2003	
15	Revision of operation on condition of the nose landing gear type 793-HPK-185-19, 793-HPK-185-19-7.	0-3, 0-4, 0-6, 4-5, 4-6, 5-10, 6-16	Jan 14, 2005	
16	Formal arrangements of accompanying technical documentation	0-3, 0-4, 0-6, 2-15, 3-3, 4-13, 5-5, 5-10, 5-18	Jun 20, 2006	
17	Revision of the airworthiness limitation	0-3, 0-4, 0-6, 3-5, 3-6, 5-8, 9-1, 9-2, 9-3, 9-4, 9-5, 9-6	Mar 8, 2007	
18	Formal arrangements, reminder from aircraft operation near of the user	0-1, 0-3, 0-4, 0-6, 1-3, 2-2, 2-15, 2-61A, 2-63C, 2-63D, 4-24, 5-5, 5-9, 5-12	Jan 10, 2009	
19	Formal arrangements, reminder from aircraft operation near of the user	0-3, 0-4, 0-6, 5-10, 5-12, 5-21b, 5-26	Nov 1, 2010	
20	Z 242 L aircraft operation with "aerobatic" wings - revision of the airworthiness limitation	0-3, 0-4, 0-6, 5-5, 5-6, 5-7, 5-8, 5-9, 5-10, 5-11, 5-12, 9-1, 9-2, 9-3, 9-4, 9-5, 9-6, 9-7, 9-8	Jun 1, 2013	
21	Implementation of replacement of broken windshield of sliding canopy	0-3, 0-4, 0-6, 7-21	Oct 24, 2014	
22	Revision of the airworthiness limitation	0-3, 0-4, 0-6, 9-1, 9-2, 9-3, 9-4, 9-5, 9-6, 9-7, 9-8	Mar 15, 2016	
23	Formal arrangements, reminder from aircraft operation near of the user	0-3, 0-4, 0-6, 1-8, 2-37, 5-10	Jun 8, 2016	

1.6. IMPORTANT MARKINGS ON THE AIRCRAFT

Text	Text location
FUEL 100 LL 60 L 16 US GALS CAUTION DON'T OPEN THE CAP WHEN THE FUEL IN AUXILIARY TANKS	Main tanks filling caps (both wings)
FUEL 100 LL 55 L 14,5 US GALS CAUTION EMPTY FOR ACROBATIC	Wing tip tanks filling caps (both wings)
OIL 8 LITERS	Door on the right engine cowl
DON'T PUSH HERE	Ailerons and wing flaps upper side
DON'T STEP HERE	Leading edge at wings root, wing flaps at fuselage
DON'T LIFT HERE	Stabilizer, Wing tips
SUPPORT HERE	Fuselage: - down, behind firewall - below tail fin (behind bulkhead No. 4)
28 V, 150 A	External source socket on the left side of the fuselage
AERO SHELL FLUID 4 FILL 400 + ¹⁰ kPa 58 + ² psi OPERATION 400 + ¹⁰ kPa 58 + ² psi - 40 - 4	Nose wheel shock absorber
TIRE (BARUM) 250 ± 10 kPa 36 ± 2 psi TIRE (GOODYEAR) 180 ± 10 kPa 26 ± 2 psi	Nose wheel fairing
FILL BRAKES WITH AEROSHELL FLUID 41	Main landing gear leg
TIRE 190 ± 10kPa 27 ± 2 psi	Main wheels fairings
CONNECT GROUNDING CABLE FROM THE FUEL UNIT HERE	At filler caps of all fuel tanks
QUICK DRAIN VALVE	At quick drain valves of the fuel tanks on the bottom side of the wings
MAIN DRAIN VALVE	At the fuselage bottom cover, close to the fuel drain valve
STATIC VENT KEEP CLEAN	The left and the right side of the fuselage rear part
ELT HERE	Fuselage right side behind the cabin, marks ELT location, if installed

Fig. 2-18 Cockpit General Dimensions (informative)





Fig. 2-19 Canopy Emergency Release



A - Direction of lever motion to release the canopy during an emergency
B - Push upward as shown for emergency release

- 1 - Canopy emergency release lever
- 2 - Canopy slide suspensions
- 3 - Handle with the lock for canopy opening
- 4 - Crash axe installation (items 5, 6, 7, 8)
- 5 - Crash axe holder (on sliding canopy frame)
- 6 - Crash axe
- 7 - Crash axe cover
- 8 - Saddlery thread with seal (subsection 6.2.2, point 6)

[illegible]